### Installation Instructions



# 12, 15 and 20 Series Drills **Folding Markers**

#### Used with:

- 1200, 1210 and 1220
- 1500, 1510 and 1520
- 2000, 2010 and 2020



When you see this symbol, the subsequent instructions and warnings are serious - follow without exception. Your life and the lives of others depend on it!

### **General Information**

These instructions explain how to install the markers. The markers fold and unfold hydraulically for field operation. The marker disks leave a line for the drill operator to follow on the next field pass. Markers are mounted on the drill frame.

These instructions apply to:

113-490A 15-FOOT DUAL FF NO-TILL MKR W/SEQ 113-491A 20-FOOT DUAL FF NO-TILL MKR W/SEQ 113-457A 20-FOOT DUAL NO-TILL HYD FF MKR-94

### **Manual Update**

Refer to the drill operator's manual for detailed information on safely operating, adjusting, troubleshooting and maintaining the markers. Refer to the parts manual for part identification.

- 12, 15 and 20 Series Drill Operator's Manual . .118-389M-A

### **Before You Start**

Beginning on page 4 are detailed lists of parts included in the marker packages. Use these lists to inventory parts received.

# **Assembly Instructions**


### **Assembling Markers**

Refer to Figure 1.

- Lower drill into field position. Allow 9 feet on each end of a 15-foot drill and 11 feet on each end of a 20-foot drill for marker assembly.
- Mount first marker section (1) on drill 6-by-6-inch frame tube. Mount plate so edge (2) is 3 1/2 inches (8.89 cm) from end of drill frame. On 20-foot drills, also install marker mount support (3) onto marker mount as shown. Secure mount with 3/4-by-6-by-7 3/4-inch u-bolts (4), lock washers (5) and nuts (6).
- Remove port plugs on cylinder and carefully unfold first marker section. Rotate hinge section (7) into a horizontal position.
- Align holes of break-away section (8) with holes in hinge section. Bolt sections together with stop block (9) on breakaway section facing up. Use 5/8-inch pivot bolt (10), lock nut (11), 3/8-by-1 3/4-inch, grade 2 shear bolt (12) and lock nut (13).

IMPORTANT: Be sure shear bolt is a grade 2 bolt. Failure to use a grade 2 bolt can cause marker damage.

- 5. Repeat steps for other marker.
- Adjust marker disks so they are square with ground when markers are lowered in field position. Refer to Marker Adjustments, "Adjustments," in operator's manual.



© Copyright 1999 Printed 4/9/04 113-477M **1** 

### **Assembling Transport Arm**

For 20-foot drills, assemble transport arm as follows. Refer to Figure 2.

- Assemble transport-arm mount (1) onto 6-by-6-inch drill frame tube about 36 inches (91.44 cm) in from drill edge (2). Use 3/8-inch u-bolts (3), flat washers, lock washers and hex nuts (4).
- Assemble marker-saddle arm (5) onto transport-arm mount at a height (6) of 32 1/2 inches (82.55 cm). Secure with 1/2inch u-bolts (7), lock washers and hex nuts (8).
- Mount marker saddle (9) onto marker-saddle arm with 1/2inch u-bolts (10), lock washers and hex nuts (11). Adjust marker saddle as needed to ensure marker break-away arm rides in middle of marker saddle.




Figure 2
Transport Carrier Assembly, 20 Series Drills

4. Repeat steps for other transport arm.

### **Installing Marker Hydraulics**

#### Without Sequence Valve

Refer to Figure 3.

- Install elbow fittings (1) in cylinder ports.
- At rod end of each cylinder, install an adaptor (2) into elbow fitting. Install a needle valve (3) in adaptor.




Figure 3
Assemble Needle Valve

- Connect hydraulic hoses to fittings and route hydraulic hoses es to tractor outlets. Route hydraulic hoses through transport-carrier mount at cutout. Use black cable ties to secure hydraulic hoses to drill frame.
- Using orange cable ties, secure a plastic hose holder to each pair of hydraulic hoses near tractor outlets. See Figure 4.
- 5. Proceed with "Bleeding Marker Hydraulics," page 3.

#### With Sequence Valve

Refer to Figure 5.

- Mount sequence valve on drill using mounting plate (1). Bolt plate to inside end of left-hand-box panel (2) using one 1/2inch hex bolt (3).
- 2. Bolt valve (4) to mounting plate with two 3/8-by-3/4-inch hex bolts (5) and lock washers (6).
- 3. Install elbow fittings in cylinder ports.
- Use hoses provided to connect valve ports to cylinders. Refer to Figure 5 for port connections.
- Connect your own hydraulic hoses to ports on front of valve. Route hoses to tractor outlets.
- 6. Using orange cable tie, secure plastic hose label to hydraulic hoses near tractor outlets. See Figure 4.




Figure 4
Install Hose Label

7. Proceed with "Bleeding Marker Hydraulics," page 3.

### Assembly




Figure 5
Hydraulic Assembly, Markers with Sequence Valve

## **Bleeding Marker Hydraulics**



# **CAUTION!**

You may be injured if hit by a folding or unfolding marker. Markers may fall quickly and unexpectedly if the hydraulics fail. Never allow anyone near the drill when folding or unfolding the markers.



# **WARNING!**

Escaping fluid under pressure can have sufficient pressure to penetrate the skin. Check all hydraulic lines and fittings before applying pressure. Fluid escaping from a very small hole can be almost invisible. Use paper or cardboard, not body parts, and wear heavy gloves to check for suspected leaks. If injured, seek medical assistance from a doctor that is familiar with this type of injury. Foreign fluids in the tissue must be surgically removed within a few hours or gangrene will result.

- 1. Check that tractor hydraulic reservoir is full.
- With both markers lowered into field position, loosen hydraulic-hose fittings at rod and base ends of marker cylinders. If applicable, loosen fittings on back side of sequence valve.

IMPORTANT: Never bleed an O-ring fitting. Instead, bleed a nearby pipe or JIC fitting.

With tractor idling, activate tractor hydraulic valve until oil seeps out around a loosened fitting. Tighten that fitting.

IMPORTANT: JIC fittings do not require high torque. JIC and O-ring fittings do not require sealant. Always use liquid pipe sealant when adding or replacing pipe-thread fittings. To avoid cracking hydraulic fittings from over tightening, do not use plastic sealant tape.

- Reactivate tractor hydraulic valve until oil seeps out around another loosened fitting. Tighten that fitting. Repeat process until all loosened fitting have been bled and tightened.
- 5. Adjust marker folding to a safe speed. Refer to *Marker Adjustment*, "Adjustments," in the operator's manual.

# 113-490A 15-Foot Dual Markers with Sequence

Your Kit Includes:

Qty.	Part No.	Part Description
1	113-180H	LH FIRST SECTION
1	113-188H	RH FIRST SECTION
1	113-191H	LH MARKER BREAKAWAY TUBE
1	113-193H	RH MARKER BREAKAWAY TUBE
2	113-248D	PIN 1 OD X 4.34 USABLE
2	113-312D	FIRST PIVOT SHAFT
2	113-313D	SECOND PIVOT SHAFT
2	113-324D	CYLINDER STOP
4	113-325D	STOP BUSHING
2	113-354D	13' MARKER TUBE 46 1/2 LONG
1	113-458H	L.H. MARKER MOUNT
1	113-459H	R.H. MARKER MOUNT
1	113-467H	LIFT LUG CHANNEL R.H.
1	13-468H	LIFT LUG CHANNEL L.H.
4	113-491D	ADJUST MOUNT SPACER TUBE +
2	113-503H	MARKER DISK ADJUST MOUNT
2	113-564S	2020 MARKER DISC & HUB ASSY
4	800-001C	GREASE ZERK STRAIGHT 1/4-28
4	801-054C	SCREW SET SQ HD 1/2-13X1 GR
8	802-099C	HHCS 1/2-13X3 1/4 GR5
4	802-115C	HHCS 5/16-18X2 GR5
2	802-249C	HHCS 1/2-13X4 1/2 GR5 SPTHD
2	802-253C	HHCS 3/8-16X1 3/4 GR2
2	802-254C	HHCS 5/8-11X5 1/2 GR5
4	803-011C	NUT LOCK 5/16-18 PLT
2	803-013C	NUT LOCK 3/8-16 PLT
2	803-019C	NUT LOCK 1/2-13 PLT
8	803-020C	NUT HEX 1/2-13 PLT
2	803-024C	NUT LOCK 5/8-11 PLT
2	803-036C	NUT HEX JAM 1/2-13 PLT
8	804-015C	WASHER LOCK SPRING 1/2 PLT
16	804-017C	WASHER FLAT 1/2 USS PLT
4	804-029C	WASHER FLAT 1 SAE
4	805-058C	PIN COTTER 3/16 X 2
2	810-205C	CYL 2X20X1.12 ROD (TIE) 1 P
1	113-477M	MANUAL 94 3PT MARKER
1	113-488D	SEQUENCE VALVE MOUNT BRACKE
2 6	113-507H	MARKER MOUNT SUPPORT WMNT CABLE TIE 28 LONG
2	800-035C 802-014C	HHCS 3/8-16X3/4 GR5
8	803-027C	NUT HEX 3/4-10 PLT
2	804-013C	WASHER LOCK SPRING 3/8 PLT
8	804-013C	WASHER LOCK SPRING 3/8 PLT WASHER LOCK SPRING 3/4 PLT
4	806-093C	U-BOLT 3/4-10 6 1/32 X 7 3/
1	810-197C	VALVE,SEQUENCE SHOEMAKER
4	811-169C	EL 9/16MJIC 9/16FJIC
4	811-281C	EL 3/8FNPT 9/16MORB
2	811-448C	HH1/4R1 156 3/8MNPT 9/16FJI
2	811-449C	HH1/4R1 176 3/8MNPT 9/16FJI
1	800-300C	CABLE TIE 2 DIA MIN - ORG
1	817-348C	PLASTIC HOSE LABEL
•	017 0-100	

# 113-457A 20-Foot Dual Markers

Your Kit Includes:

Qty.	Part No.	Part Description
2	113-203H	SUPPORT ARM SADDLE - 20'
2	113-203H 113-223H	MARKER TRANS ARM MOUNT WDM1
2	113-526H	MARKER SADDLE MOUNT ARM WMN
2	113-500H	MARKER MOUNT SUPPORT WMNT
8	800-035C	CABLE TIE 28 LONG
8	803-014C	NUT HEX 3/8-16 PLT
16	803-020C	NUT HEX 1/2-13 PLT
8	803-027C	NUT HEX 3/4-10 PLT
8	804-012C	WASHER FLAT 3/8 SAE PLT
8	804-013C	WASHER LOCK SPRING 3/8 PLT
16	804-015C	WASHER LOCK SPRING 1/2 PLT
8	804-023C	WASHER LOCK SPRING 3/4 PLT
8	806-005C	U-BOLT 1/2-13 X 2 X 3 GR 5
4	806-051C	U-BOLT 3/8-16 X 6 1/32 X 7
4	806-093C	U-BOLT 3/4-10 6 1/32 X 7 +
2	810-058C	VALVE 3/8 NEEDLE
2	811-044C	AD 3/8MNPT
4	811-281C	EL 3/8FNPT 9/16MORB
1	113-477M	MANUAL 94 3PT MARKER
2	811-015C	HH1/4R1 192 3/8MNPT 1/2MNPT
2	811-297C	SP HH1/4R1 212 3/8MNPT-W/AD
1	113-180H	LH FIRST SECTION
1	113-188H	RH FIRST SECTION
2	113-248D	PIN 1 OD X 4.34 USABLE
2	113-312D	FIRST PIVOT SHAFT
2 2	113-313D	SECOND PIVOT SHAFT
4	113-324D 113-325D	CYLINDER STOP STOP BUSHING
2	113-325D 113-354D	13' MARKER TUBE 46 1/2 LONG
1	113-354D 113-458H	L.H. MARKER MOUNT
1	113-459H	R.H. MARKER MOUNT
1	113-467H	LIFT LUG CHANNEL R.H.
1	113-468H	LIFT LUG CHANNEL L.H.
4	113-491D	ADJUST MOUNT SPACER TUBE
2	113-503H	MARKER DISK ADJUST MOUNT
2	113-564S	2020 MARKER DISC &3HUB A +
2	113-646H	20' MARKER BREAKAWAY
4	800-001C	GREASE ZERK STRAIGHT 1/4-28
4	801-054C	SCREW SET SQ HD 1/2-13X1 GR
8	802-099C	HHCS 1/2-13X3 1/4 GR5
4	802-115C	HHCS 5/16-18X2 GR5
2	802-249C	HHCS 1/2-13X4 1/2 GR5 SPTHD
2	802-253C	HHCS 3/8-16X1 3/4 GR2
2	802-254C	HHCS 5/8-11X5 1/2 GR5
4	803-011C	NUT LOCK 5/16-18 PLT
2	803-013C	NUT LOCK 3/8-16 PLT
2	803-019C	NUT LOCK 1/2-13 PLT
8	803-020C	NUT HEX 1/2-13 PLT
2 4	803-024C	NUT LOCK 5/8-11 PLT NUT HEX JAM 1/2-13 PLT
4 8	803-036C 804-015C	WASHER LOCK SPRING31/2 P
o 16	804-017C	WASHER FLAT 1/2 USS PLT
4	804-017C 804-029C	WASHER FLAT 1/2 053 FLT WASHER FLAT 1 SAE
4	805-058C	PIN COTTER 3/16 X 2
2	810-205C	CYL 2X20X1.12 ROD (TIE) 1 P
2	800-300C	CABLE TIE 2 DIA MIN - ORG
2	817-348C	PLASTIC HOSE LABEL
-		

# 113-491A 20-Foot Dual Markers with Sequence

Your Kit Includes:

Qty.	Part No.	Part Description
1	113-477M	MANUAL 94 3PT MARKER
2	113-203H	SUPPORT ARM SADDLE - 20'
2	113-223H	MARKER TRANS ARM MOUNT WDMT
1	113-488D	SEQUENCE VALVE MOUNT BRACKE
2	113-506H	MARKER SADDLE MOUNT ARM WMN
2	113-507H	MARKER MOUNT SUPPORT WMNT
8	800-035C	CABLE TIE 28 LONG
2	802-014C	HHCS 3/8-16X3/4 GR5
8	803-014C	NUT HEX 3/8-16 PLT
16	803-020C	NUT HEX 1/2-13 PLT
8	803-027C	NUT HEX 3/4-10 PLT
8	804-012C	WASHER FLAT 3/8 SAE PLT
10	804-013C	WASHER LOCK SPRING 3/8 PLT
16	804-015C	WASHER LOCK SPRING 1/2 PLT
8	804-023C	WASHER LOCK SPRING 3/4 PLT
8 4	806-005C	U-BOLT 1/2-13 X 2 X 3 GR + U-BOLT 3/8-16 X 6 1/32 X 7
4	806-051C 806-093C	U-BOLT 3/6-16 X 6 1/32 X 7 U-BOLT 3/4-10 6 1/32 X 7 3/
1	810-197C	VALVE,SEQUENCE SHOEMAKER
4	811-169C	EL 9/16MJIC 9/16FJIC
4	811-281C	EL 3/8FNPT 9/16MORB
2	811-450C	HH1/4R1 192 3/8MNPT 9/16FJI
2	811-451C	HH1/4R1 212 3/8MNPT 9/16FJI
_ 1	113-180H	LH FIRST SECTION
1	113-188H	RH FIRST SECTION
2	113-248D	PIN 1 OD X 4.34 USABLE
2	113-312D	FIRST PIVOT SHAFT
2	113-313D	SECOND PIVOT SHAFT
2	113-324D	CYLINDER STOP
4	113-325D	STOP BUSHING
2	113-354D	13' MARKER TUBE 46 1/2 LONG
1	113-458H	L.H. MARKER MOUNT
1	113-459H	R.H. MARKER MOUNT
1	113-467H	LIFT LUG CHANNEL R.H.
1	113-468H	LIFT LUG CHANNEL L.H.
4	113-491D	ADJUST MOUNT SPACER TUBE
2	113-503H	MARKER DISK ADJUST MOUNT
2	113-564S	2020 MARKER DISC &3HUB A +
2	113-646H	20' MARKER BREAKAWAY
4	800-001C	GREASE ZERK STRAIGHT 1/4-28
4 8	801-054C 802-099C	SCREW SET SQ HD 1/2-13X1 GR HHCS 1/2-13X3 1/4 GR5
4	802-099C 802-115C	HHCS 5/16-18X2 GR5
2	802-113C 802-249C	HHCS 1/2-13X4 1/2 GR5 SPTHD
2	802-253C	HHCS 3/8-16X1 3/4 GR2
2	802-254C	HHCS 5/8-11X5 1/2 GR5
4	803-011C	NUT LOCK 5/16-18 PLT
2	803-013C	NUT LOCK 3/8-16 PLT
2	803-019C	NUT LOCK 1/2-13 PLT
8	803-020C	NUT HEX 1/2-13 PLT
2	803-024C	NUT LOCK 5/8-11 PLT
4	803-036C	NUT HEX JAM 1/2-13 PLT
8	804-015C	WASHER LOCK SPRING31/2 P
16	804-017C	WASHER FLAT 1/2 USS PLT
4	804-029C	WASHER FLAT 1 SAE
4	805-058C	PIN COTTER 3/16 X 2
2	810-205C	CYL 2X20X1.12 ROD (TIE) 1 P
1	800-300C	CABLE TIE 2 DIA MIN - ORG
1	817-348C	PLASTIC HOSE LABEL